



# USER GUIDE FOR PORTABLE ROCKET STOVE




ALWAYS USE:


1. Well dried split firewood.
2. The firewood stand.
3. The correct - sized pot.



1. Do not force or use wood which is bigger than the fire chamber.
2. Wood must not touch the back wall in order to avoid damaging the insulative bricks.



Never load firewood without using the wood stand.



Do not use pots that are smaller / bigger than the stove skirt.



Carry the stove upright when moving it from one place to another.



Do not roll the stove when moving it from one place to another.



Do not carry the stove on its side when moving it from one place to another.



Do not place extra weight on the stove skirt.



Always keep and use dry and well split wood.




Do not use wet wood.



Quench the firewood left after cooking with sand.



Do not put water in the stove skirt or the fire chamber.



Always keep the stove in a well protected area sheltered from rains.



Do not leave the stove out in the rain; keep it well protected from rains.