













Tikikil Stove Do's & Don'ts

 <p>Do use the right size pot. Leave a 1cm gap between the pot and the skirt. Smaller pots can also be used but with less efficiency.</p>	 <p>Always use a pot lid!</p>	<p>Don't use pots which are too big or too small.</p>  
 <p>Do use the shelf.</p>	<p>Don't remove the shelf to add extra fuel wood.</p> 	
 <p>Do use long, thinly chopped pieces of wood.</p>	<p>Don't use big pieces of wood. Don't overfill the combustion chamber.</p> 	

Lighting the stove

<p>Chop wood and then store it in dry place for at least one month before use.</p> 	<p>The stove can be fired from the top.</p>  <p>After lighting, only feed wood at the fuel inlet.</p> 	<p>Clean the combustion chamber after each meal preparation. Avoid water or liquid from being spilled over on the stove or you may risk damaging the clay liner.</p> 
---	---	--



A Double skirt model is also available. The operation is the same as the single skirt model except this is with two skirts for use with two different size ranges of pots. Use the smaller skirt for pots of sizes 27cm diameter or less. For pots between 27 and 31cm diameter remove the smaller skirt to use the big one.

For additional information please contact:

GIZ-ECO (former GTZ-SUN:E)
Gurdsholla Area, Kebele 12/13,
Bole Sub-city, Addis Ababa
P.O.Box 12994
Tel.: +251 11 645 1020
Fax: +251 11 646 3066